


- | | |
|----------------------------------|---|
| 1 Fuel inlet connection | 9 Accelerator pump |
| 2 Pull-down bellows | 10 Throttle plate abutment screw |
| 3 Float chamber vent tube | 11 Mixture control screw |
| 4 Float chamber vent tube | 12 Throttle plate dash-pot |
| 5 Thermo time valve | 13 Fuel hose to connection (1) |
| 6 Part load enrichment | 14 Vapor separator |
| 7 Throttle lever for AT vehicles | 15 Fuel inlet connection from fuel pump |
| 8 Starter cover | 16 Fuel return connection |



CONTENTS

Maintenance
Repair
Note

- A. TESTS AND SETTINGS, carburettor mounted
 - 1. Idle correction
 - 2. Throttle plate dash-pot
 - 3. Starting device
 - 3.1 Fast idle
 - 3.2 Pull-down device
 - a) Pull-down bellows
 - b) Thermo time valve
 - 3.3 Choke plate
 - 3.4 Positive opening of choke plate (wide open kick)
 - 3.5 Starter cover position
 - 4. Depression bellows stage II
 - 5. Filter in fuel inlet
 - 6. Enrichment tube
 - 7. Gas linkage
 - 8. Intake air preheating
 - 9. Connection diagram, depression hoses and fuel lines
- B. SETTINGS, carburettor removed
 - 1. Basic setting throttle plate stage II
 - 2. Release and positive return of stage II
 - 3. Pull rod for stage II
 - 4. Starting device
 - 4.1 Leakage test of pull-down bellows
 - 4.2 Choke plate
 - a) Gap "a1" (wide)
 - b) Gap "a" (small)
 - 4.3 Position of cam
 - 4.4 Cold starting setting, throttle plate gap
 - 5. Float/level
 - 6. Accelerator pump
 - 6.1 Direction of injection spray
 - 6.2 Injection volume
- C. TROUBLE SHOOTING

MAINTENANCE

If necessary check idle setting and if necessary correct. If a setting as specified is not possible or a complaint has been received check the carburettor according to the trouble shooting table, if necessary remove and repair.

Note: After engine washing protect the carburettor from corrosion by application of spray BREAK FREE CLP or WD 40 or Uni-Spray Termal.

REPAIR

Remove carburettor, clean externally and disassemble. Clean castings and steel parts in special cleaning bath, rewash with test fuel DIN 51 632. Before cleaning remove filter in the fuel inlet, see chapter A.5. Blow out drillings and channels with compressed air. A repair kit available at the carburettor service outlets has to be used for the assembly. Check the free movement of all moving parts.

Tightening torque for carburettor fixing: 7 Nm.

NOTE

Screws protected by means of protective caps or protection lacquer may not be re-set. In case these screws have been maladjusted perform the setting according to the chapters in question. After the setting replace the protection.

Setting data if not listed may be taken from the corresponding model sheets (spare parts lists).

A. TESTS AND SETTINGS, carburettor mounted

1. IDLE CORRECTION (figure 1, 2)

Idle rpm of vehicles with

4/5 speed gear	: 900 to 950 rpm
automatic transmissions:	800 to 850 rpm
idle emission value	: 1.0 to 1.5 vol.-% CO

Conditions:

- flawless functioning of the engine
 - oil temperature approx. 70 °C
 - ignition system in good condition
 - intake system without leakages
 - clean air cleaner mounted
 - intake air preheating in good operating condition
 - gas linkage in good condition
 - electric consumers switched-off
 - hose for crankcase ventilation withdrawn and closed to the air cleaner
 - test instruments connected
 - the adjusting screw (3) may not touch the cam (4), see figure.
 - with automatic transmission selector lever on "P".
- set idle rpm by means of the throttle plate abutment screw (1).
- correct emission value if necessary by means of the mixture control screw (2)

Remark: If this setting is not possible, see "trouble shooting table".

2. THROTTLE PLATE DASH-POT (figure 3) (Only vehicles with automatic transmission)

lift "H" = 3.0 ± 0.5 mm

Condition: Idle setting correct and lever (1) in idle position.

- Release counter nut (3).
- Turn dash-pot (2) till a gap of 0.05 mm exists between dash-pot (2) and lever (1).
- Turn dash-pot (2) by 2 1/2 turns downwards and tighten counter nut (3).

3. STARTING DEVICE

3.1 Fast idle (figure 4)

Conditions: Engine at operating temperature, idle correctly set.

- Place adjusting screw (3) on the second highest step of the cam (4).
- Start engine without depressing the accelerator pedal.
- Correct fast idle rpm with fully opened choke plate by means of the adjusting screw (3).

3.2 Pull-down device

Conditions: Hoses and hose connections in good condition.

a) Pull-down bellows (figure 5)

- Withdraw hose from connection (2) and close connection.

- Connect manual vacuum pump as shown and create pressure differential (approx. 300 mbar) in the pull-down bellows (1).
- If a pressure differential drop is noted, remove leakages.

b) Thermo time valve (figure 6)

below approx. + 28 °C = valve has passage
above approx. + 35 °C = valve closed

Conditions: Thermo time valve (3) at a stabilized temperature of approx. +20 °C
Good current supply at the plug (4) when the ignition is switched on, minimum 11.5 V.

- Connect ohmmeter according to illustration.
Nominal value: at 20 to 30 °C = $6 \pm 1.5 \Omega$
- Connect manual vacuum pump as shown in the illustration and actuate pump.
The thermo time valve must have passage.
- Switch on the ignition, connect the plug (4) on the thermo time valve (3) and determine by continual actuation of the manual pump the switch over time (till the pressure differential increases).
Switch over time at + 20 °C = 4 to 10 seconds
- If necessary replace thermo time valve.
- Connect hoses as shown in figure 7.

3.3 Choke plate

Conditions: Pull-down device in good condition according to chapter 3.2.
Starter cover removed.

- Make sure that when the choke plate is in starting position, the throttle plate is completely closed. If necessary check and if necessary set the clearance "A" (figure 8) between the diaphragm rod (2) and the lever (3).

a) Adjustment of clearance "A" (figure 8)

- Lift throttle plate, push intermediate lever (1) in direction of arrow and again release throttle plate. The adjusting screw (4), figure 91, rests on the highest step of cam (5).
- Check clearance "A", if necessary correct by bending lever (3), figure 8.
Clearance "A": 0.0 to 1.0 mm

b) Choke plate gap "a1" (wide) (figure 9a, b, 10)

- Close choke plate and place the adjusting screw (4) on the highest step of the cam (5).
- Create pressure differential in the pull-down device, see chapter A.3.2a figure 5.
- Push intermediate lever (1) lightly in direction of arrow and check gap according to figure 9b.
- Correction by means of the adjusting screw (6) figure 10.

c) Choke plate gap "a" (small)

Adjust with carburettor removed according to chapter B. 4.2.b.

3.4 Positive opening of choke plate (wide open kick) (figure 11 a, b)

- Lightly push intermediate lever (1) in direction of arrow and hold in that position, eventually use elastic ring.
- Place throttle lever in full load position and check opening of choke plate according to figure 11 b.

Opening too small:

Increase gap "B" of the segment (2) by means of screw driver

Opening too wide:

Decrease gap "B" of the segment (2) by means of pliers.

3.5 Starter cover position (figure 12)

- The markings (arrows) must be in line.

4. DEPRESSION BELLOWS STAGE II (figure 13)

- Connect manual vacuum pump according to illustration and create pressure differential.
- If pressure differential drop is noted the depression hose or the depression bellows is defective.
- If necessary replace.

5. FILTER IN THE FUEL INLET (figure 14)

Before cleaning the carburetter the filter (arrow) has to be removed.

The filter may be withdrawn by means of an M3-screw which is turned into the opening by 5 mm.

The filter has to be replaced.

6. ENRICHMENT TUBE (figure 15)

The discharge of the enrichment tube (1) is directed vertically into the center of the diffuser (2).

Height above diffuser: 27.5 ± 1.0 mm

7. GAS LINKAGE

- Adjust gas cable in idle position of the throttle lever without tension (light clearance in the gas cable).

8. INTAKE AIR PREHEATING (figure 16)

Intake air controlled as function of load and temperature

When the engine is cold (approx. -20°C of the wax element (13)) the control flap (14) must completely close the cold air channel (A). Eventually check by means of cold spray.

With running or warming-up engine the warm air channel (B) must be closed.

When these positions are not reached the bimetal regulator (11) or the wax element (13) or the depression bellows (12) are defective.

9. CONNECTION DIAGRAM, depression lines and fuel lines (figure 16)




Figure 16

- | | | |
|-------------------------------|--|-----------------------|
| A cold air supply | 5 vapor separator | 10 air cleaner |
| B warm air supply | 6 fuel pump | 11 bimetal regulator |
| 1 carburetter | 7 fuel supply | 12 depression bellows |
| 2 pull-down bellows | 8 fuel return | 13 wax element |
| 3 thermo time valve | 9 depression bellows, ignition distributor | 14 control flap |
| 4 depression bellows stage II | | |

B. SETTINGS, carburetter removed

The measuring and control devices mentioned below may be purchased from our local general agent.

1. BASIC SETTING

CHOKE PLATE STAGE II (figure 17, 18)

- Turn out throttle plate abutment screw (1) till it is no longer in contact.
- Place measuring device (2) in position and set measure "a" by means of throttle plate abutment screw (1).

2. RELEASE AND POSITIVE RETURN OF STAGE II (figure 19)

Condition: Throttle plate stage I in idle position.

a) Opening point "Y"

- set distance (Y) by bending fork (1).

b) Closing point "Z"

- Set distance (Z) by bending fork (1).

Important: Measure at the smallest opening.

3. PULL ROD FOR STAGE II (figure 20)

Conditions: Chapter B.1. and B.2. correct.

- Unhook ball cage (1) and check pretension "b".
Nominal value: 0.5 to 2.0 mm
- If necessary replace depression bellows stage II.

4. STARTING DEVICE

4.1 Leakage test of pull-down bellows (figure 21)

Conditions:

- Starter cover removed and adjusting screw (4) figure 22 a on highest step of cam (5).
- Vacuum tester (2) connected as shown in figure 21, control valve (3) closed.
- Hold choke plate closed by depressing lever (1) and create pressure differential of approx. 750 mbar.
(Overpress pull-down).
- Cut off vacuum tester and perform leakage test. In case of pressure differential drop replace pull-down bellows.
- Release lever (1) and close connection (7) by means of a cap (8).
- Create pressure differential (approx. 750 mbar).
- Cut off vacuum tester and perform leakage test. In case of pressure differential drop replace pull-down bellows.

4.2 Choke plate (figure 21-23)

Conditions: See chapter B.4.1.

Place screw (4) figure 22a on highest step of cam (5). Clearance "A" figure 8 correct.

a) Gap "a1" (wide)

- Close connection (7) by means of cap (8) and create pressure differential (approx. 750 mbar).
- Push lever (1) lightly in direction of arrow and check gap according to figure 22b. Correction by means of screw (6) figure 23.

b) Gap "a" (small)

Checking and adjustment only required if the color protection (10) has been damaged and after the pull-down bellows has been replaced respectively.

- Remove cap (8) from connection (7) and switch on vacuum testing device.
- Create a pressure differential of approx. 200 mbar by depressing the lever in direction of arrow and check gap according to figure 22b, correction by means of screw (9) figure 21.
- Mount starter cover and align markings.

4.3 Position of cam (figure 24, 25)

Condition: Adjustments chapter B.4.2. correct.

- Place screw (4) on the highest step of cam (1).
- Close connection (7) figure 21 by means of cap, connect vacuum testing device (2) figure 21 as shown and create pressure differential.

- Lightly push lever (3) figure 24 in direction of arrow, open throttle plate and close again.
Screw (4) must rest on second highest step of cam (1) for gap "a", see figure 24b.

"a" = 0.0 to 1.0 mm

- Correction by bending lever (2) figure 24b and 25.

Important: Make sure that the return springs, arrows figure 25, are in the correct position.

4.4 Cold starting adjustment, throttle plate gap (figure 26)

- Place adjusting screw (1) on highest step of cam (2).
- Measure throttle plate gap (arrow) according to figure 26.
- Correction by means of adjusting screw (1).

Note: Check fast idle rpm after the carburetter has been mounted, if necessary correct, see chapter A.3.1.

5. FLOAT / LEVEL (figure 27, 28)

- Remove carburetter cover.
When remounting the cover make sure the spring (arrow) figure 29 is in the correct position.
- Check height "h" and the float weight.

Important: The valve pin (1) of the float needle may not be depressed by the float weight when the height is measured.

The fuel level cannot be adjusted. It results by using a flawless float.

- Make sure that the float (2) with float needle, see figure 28, is correctly mounted.

6. ACCELERATOR PUMP

6.1 Direction of injection spray (figure 30)

- Insert (press fit) injector tube so that the fuel spray is in direction of recess (arrow).

6.2 Injection volume (figure 31)

Conditions: The fuel chamber must have a normal fuel level during the measurement i.e. the fuel must be replenished.

The injection must begin immediately upon actuation of the throttle plates.

- Use carburetter testing device.
- Turn cam (4) figure 2 and hold cam so that the adjusting screw (3) does not contact.
- Uniformly completely open and close 10 times throttle plate (approx. 1s/stroke). Wait for approx. 3 s between the strokes.
- Divide fuel quantity by 10 and compare with the nominal value.
- Correct injection volume by untightening clamping screw (1) and turning cam (2).

In direction + greater injection volume
in direction - smaller injection volume

Attention: In vehicles with automatic transmission the throttle plate dash-pot (2) figure 3 has to be turned upwards before the measuring is effected.

COMPLAINTS

COMPLAINTS																											
Cold starting (firing) _____	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Stabilization of engine run (stalling after cold starting) _____	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Cold idle (engine speed too high / too low) _____	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Cold drive away; progression cold (bad response, bucking) _____	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Automatic starter does not cut out completely or too late _____	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Warm starting (starting time more than 5 s) _____	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Idle (rough, too high, too low) _____	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Idle rpm or CO too high (not adjustable) _____	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Progression during acceleration (bucking) _____	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Progression at high rpm (to stage II) _____	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Exhaust detonations during deceleration _____	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Power (too small, stalls at full load) _____	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Excessive fuel consumption _____	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•

NOTE:

This table should only be used if the following conditions are met:

- Good functioning of the engine (timing, valves etc...)
- Ignition system in good working order and correctly set
- Intake system without leakages
- Exhaust system in good working order
- Correct control of intake air preheating
- Clean air cleaner
- Correct fuel pressure to the carburetter

CAUSE

REMEDY

- | | |
|--|--|
| 1 Incorrect operation | operate as specified |
| 2 Working conditions / driving error | service discussion with client |
| 3 Fuel not according to standard | use fuel according to standard |
| 4 Carburetter icing | use fuel according to standard / check preheating |
| 5 Dirt in the carburetter / damage by water | clean carburetter, if necessary replace |
| 6 Worn throttle spindle | replace carburetter |
| 7 Jet setting not as specified | correct |
| 8 Fuel evaporation (engine excessively rich) | hold accelerator pedal in full load position and start / try changing fuel |
| 9 Choke plate does not completely close | adjust starting device / check bimetal spring |
| 10 Choke plate or linkage hard moving or jamming | assure free movement |
| 11 Choke plate gap incorrect | adjust |
| 12 Pull-down device leaks or is defective | check, if necessary replace parts |
| 13 Starter heating incorrect or cooling water flow disturbed | check heating coil, contacts and cooling water flow |
| 14 Cam jams; incorrect position; return springs defective | assure free movement and adjust, if necessary replace carburetter cover |
| 15 Cold starting adjustment, throttle plate gap incorrect | adjust fast idle and throttle plate gap respectively |
| 16 Positive choke plate opening (wide open kick) incorrect | adjust |
| 17 Idle adjustment incorrect | correct |
| 18 Idle fuel-air jet contaminated | clean and replace respectively |
| 19 Throttle plate dash-pot jams or is incorrectly adjusted | replace and adjust respectively |
| 20 Injection volume and begin of injection respectively | check, if necessary replace |
| 21 Enrichment valve defective | replace |
| 22 Enrichment tube incorrect, bend | check, if necessary adjust |
| 23 Float needle valve leaks | clean valve, if necessary replace needle |
| 24 Float defective / incorrect level | replace float |
| 25 Erroneous air on gaskets or flange | replace gaskets |
| 26 Throttle plates do not completely open | correct gas linkage |
| 27 Basic setting throttle plate stage II incorrect | adjust |
| 28 Depression bellows stage II incorrect; pull rod incorrect | replace and if necessary adjust |



fig. 1




fig. 2




fig. 3




fig. 4




fig. 5




fig. 6




fig. 7




fig. 8




fig. 9a

fig. 9b




fig. 13




fig. 10




fig. 14




fig. 11a

fig. 11b



fig. 15




fig. 12




fig. 17



fig. 26




fig. 30




fig. 27




fig. 31




fig. 28




fig. 29